

**mitsubishi silver master
CP-TONE 310**

SERVICE MANUAL

Contents

1. Introduction	1
2. Specifications	2
3. Process Diagram	4
4. Installation Procedure	5
5. Verifying and adjusting the optical system	17
5-1 Adjustment for distortion	18
5-2 Adjusting focus	21
5-3 Adjustment of magnification	22
6. Replacing the mirror	23
7. Replacing the copy glass	24
8. Processor and dryer	25
9. Electrical System	

1. Introduction

This CP-TONE Service Manual was written as an after-sales service guide. Accordingly, please consult the “CP-TONE Operation Manual” and “Technical Manual” for information about camera operation, master, and processing liquids, etc.

Regarding the contents of this manual, changes in specifications and machine modifications may be made without notice and we ask for your kind understanding.

For parts orders and inquiries, please consult the “CP-TONE 310 Parts List” and contact Dainippon Screen with the following information.

- ◇ Machine name: CP-TONE 310
- ◇ Machine number:
- ◇ Part number/Part name:
- ◇ Quantity:
- ◇ Delivery:

Publicizing the contents and reproduction of this manual is forbidden.

Quality Warranty Section
Hikone Plant
Dainippon Screen Manufacturing Co., Ltd.

480-1 Takanomiyamachi, Hikone-shi,
Japan 522-02
Tel: 0749-24-1167

2. Specifications


	Item	Specifications
1	Master	SLM-RII , SLM-F, SPP-R (75 m roll)
2	Master width (cm)	22.9 (9"), 25.4 (10"), 27.9 (11"), 30.5 (12"), 31.0 (12 1/5")
3	Master feed length (cm)	36.0 – 48.0 (1 mm increments)
4	Lens	HEXANON GR II f = 260 mm aperture F/16 and F/22
5	Magnification and copy size (95% – 100%)	Original size (cm) 95% 32.6 × 50.5 (blank sheet exposure) 32.6 × 46.3 (available) 100% 31.0 × 48.0 (blank sheet exposure) 31.0 × 44.0 (available) Exposure size (cm) 95 – 100% 31.0 × 48.0 (available) 31.0 × 48.0 (exposure area)
6	Magnification change	Moveable lens type, manual scale adjustment
7	Copy surface	Glass bottom surface, vacuum suction top surface (air blow unit)
8	Master positioning	Back-edge nipping and automatic exposure of register marks
9	Original positioning	Lengthwise (far side) 270 mm pin bar unit
10	Exposure type	6 channel basic data input (computer controlled)
11	Optical control	Light integrator for reflection light source
12	Reflection light source	Halogen lamp 500 W × 4 (3000°K)
13	Auxiliary light source	Copy section internal flash lamp (5 W bulb)
14	Cut mark copy	Auxiliary exposure lamp (10 W bulb)
15	Contact screen	GDH (hard coat processing, negative type) 400 × 460 mm
16	C. S. Removal	C/S set before master feed, removed after exposure
17	C. S. Receiver	Receiving case installed (receives one)
18	Cutter	Cutter blade (NT) slide cut type
19	Processor	Drawer type, 400 W panel heater, thermo-control type
20	Processing fluid capacity	Developer: 8ℓ, fixer: 8ℓ, replenishment tanks: each 2ℓ
21	Dryer	500 W heater hot air dry type, HIGH/LOW switching
22	Dehumidifier	Fan, heater type (installed on master conveying section)
23	Electrical capacity	1Ø 200V 4.0 kW
24	Dimensions (cm)	163.0 × 78.0 × 116.0 (W × D × H)
25	Weight (without fluid)	260 kg

Options

	Item	Specifications
1	Contact screen	GPH (hard coat processing, positive type) 4 in one set (for 4 colors) 400 × 460 mm
2	Contact screen collecting container	Receives 4, includes 4 contact screen holders in 1 set
3	Contact screen installation fixture	Removable screw type in copy section
4	Filter holder	Manual turret type, with filter
5	Permeated light source unit	Halogen lamp 35W × 24
6	Punch stand (SFP-015)	Ø5 mm 270 mm pitch
7	Filter device	

3. Process Diagram


[Process Diagram]




4. Installation Procedure

Options

- Choose a well-ventilated site having an ambient temperature of 10 – 30°C and humidity of 40 – 70%.
 - Avoid installing in the direct sunlight.
 - Choose a site with a foundation strong enough to withstand the machine weight of 260kg.
 - Avoid sites subject to vibration.
 - Ensure that at least 40cm is provided around the machine as maintenance space.
 - Use a single-phase 200V, 4.0kW power supply.
Use wiring that meets this rating and keep voltage fluctuations to within $\pm 10\%$.
- *Earth the machine in accordance with safety standards as laid down in local bylaws and regulations.*




Unpacking



1. Remove the outer wooden packaging so that the machine is left on the wooden pallet.
2. Remove the securing bolts from the transportation fixtures (painted yellow)securing the body to the wooden pallet.
3. Pass nylon rope under the base of the machine and lift up to remove from the wooden pallet.
4. The machine is provided with casters at its base so that it can be transported easily.

Unpacking Always check this packing list when unpacking.




<u>No.</u>	<u>Name</u>	<u>Q'ty</u>
1	Body	1
2	Spool (2), spool shaft	1 set
3	Light unit (with stand)	2
4	Halogen lamp	4
5	Master receiving tray	1
6	Master stop	1
7	Drainage vat	1
8	Contact screen holder	1
9	Contact screen	1
10	Replenisher bottles	2
11	Squeegee roller	1
12	Measuring cup	1
13	Funnel	1

14	Photographic samples, test sheets	1 set
15	Standard spare parts (see next page)	1 set
16	Instruction Manual, Technical Guide	1 set


Unpacking

<u>No.</u>	<u>Name</u>	<u>Q'ty</u>
1	Screwdriver set	1 set
2	Leg bases	6
3	Spanner	1
4	Cutter blade	1
5	Oil can	1
6	Blower brush	1
7	Safety switch key	1
8	Screws, bolts	1 set
9	Glass fuses	2 each
	20A – 250V	
	10A – 250V	
	5A – 125V, 3A 250V	
	2A – 125V, 1A 125V,	
10	Spring belt	2
11	Metal polish	1
12	B cock	2

Installation Procedure



1. Move the machine to the predetermined position and place the six leg bases under the machine adjusting bolts.
2. Cut the string securing the copy table, upper cover and lens cover.
3. Open out the upper cover.
4. Place a sheet of protective paper on the copy glass and place a leveler on top.



5. Use the four adjusting bolts (two at right, two under copy table) to adjust the copy table so that it is level.


① in diagram

▶ At this time, raise the casters slightly off the floor.

6. Adjust the adjusting bolts at the left of the machine.

② in diagram.


▶ At this time, turn the adjusting bolts about one half turn (180) once they have come in contact with the floor.



7. Push the casters attached to both sides of the processor down until they come into contact with the floor. Loosen the caster securing bolts.

8. Remove the lens and mirror covers.

▶ Take care not to mark the lens or mirrors with fingerprints, etc.



9. Install the light unit (with stand) and connect each of connectors J28 and J29.
 - ▶ Match the (▲) marks.
10. Install the halogen lamp.
 - ▶ Do not hold the lamp with the bare hand as this will shorten the life of the lamp.
11. Install the master receiving tray, drainage vat, etc. in place.
12. Install the cutter blade. (See Instruction Manual.)
13. Set the master in place. (See Instruction Manual.)

Mixing Chemical Solutions


1. Remove the units inside the processor, and clean the units and the inside of the tanks. Turn the rollers before pouring in the chemical solutions as they sometimes stick to each other.
2. Pour the developer and fixer into the tanks and replenisher bottles following the instructions in the Instruction Manual.

Connecting the Power Supply

1. Turn the POWER switch located at the right of the process camera to OFF.
2. After checking the power supply, connect the input lines.
3. Always earth the input lines in accordance with local bylaws and regulations.

Inspection and Adjustment

1. The CPU board is located inside the right cover. Remove this cover to access the CPU board.
Inspect the DIP switches in the CPU board and adjust if necessary.



DIP Switch Functions

- All of the DIP switches have been factory set to OFF. Change their settings as necessary at the user side.
- Turn the power supply OFF before changing the settings.

No.	Item	Use	Normal State
1	Data input	Used together with DIP switch 7.	OFF
2	Inch/mm selection	Selects the master feed unit. ON: inch OFF: millimeter	ON/OFF
3	Frequency selection	Selects between 50 and 60Hz. ON: 50Hz OFF: 60Hz	ON/OFF
4	Main exposure time	Selects between the fixed clock and the light integrator. ON: fixed clock OFF: light integrator	ON/OFF
5	Air blower selection	Selects the air blower time. ON: 10sec OFF: 5sec	OFF
6	Unused		OFF
7	Data input	Used together with DIP switch 1.	OFF
8	Maintenance mode	Used together with the mode key. Used for manual drive and input together with DIP switches 1 and 7. (See next page.)	OFF

Maintenance Mode

Functions 1 – 6 are provided in the maintenance mode. The desired mode must be switched to before operation.

Turn the power supply OFF, turn DIP switch 8 ON and then turn the power supply ON again. Then select the desired mode by using the mode key.

Function	Mode Display Cursor	Use
1	BWL	Manual mode (operation check) MANUAL MODE
2	BW	Display and input of master cut coefficient MASTER CUT DATA
3	C	Display and input of optical axis feed length AXIS FEED DATA
4	M	Display and input of cut mark exposure time 1 (for BWL and BW) CUT MARK1 (OR) TIME
5	Y	Display and input of cut mark exposure time 2 (for C, M, Y and Bk) CUT MARK2 (PAN) TIME
6	Bk	Clears RAM and EAROM (reset to defaults). RAM CLEAR

Note:

When inputting (writing) numerical values in functions 1 – 5, turn DIP switches 1 and 7 to ON in addition to DIP switch 8.

Explanation of Functions

Function 1 Manual Drive

Select "**BWL**" using the mode key and press all the keys on the control panel to enter the manual drive mode.

Key	Use
1	CUTTER ⇒ Cutter
2	DRYER HEATER ⇒ Dryer/heater
3	CLUTCH ⇒ Clutch
4	FEED MOTOR F ⇒ Feed mode (forward)
5	FEED MOTOR R ⇒ Feed mode (Reverse)
6	TRANS MOTOR ⇒ Transmotor
7	SHUTTER ⇒ Shutter
8	PUMP ⇒ Vacuum pump (suction contact only)
9	CUTMARK LAMP ⇒ Cutmark lamp
0	C·S SOLENOID ⇒ Contact screen solenoid
.	SOLENOID VALVE ⇒ Solenoid valve
C	FLASH LAMP ⇒ Flash lamp
FOCUS	MAIN LAMP ⇒ Main lamp (reflection/transmission)

Note:

- Manual drive is operative only for the time that all of the keys are pressed.
- **Two operations** cannot be performed at the same time.
- Do not leave the dryer/heater and the main lamp ON for a long time.

Function 2 Display and Input of the Master Cut length Coefficient

● **Checks and Adjustments**

1. Set the most frequently used length.
Ex: set 480mm
2. Actually feed a master and measure the length of the master after is has been cut.
 - ▶ This feed length is the feed length from the register mark (cut mark). Its total length is about 30mm longer then the set value.
 - ▶ The first plate after setting the master in place will differ slightly in length. So always measure the length of the 2nd plate.

Ex: let the measured value be 485mm

Function 6

RAM Clear, EAROM Clear (Resetting of Defaults)

◇ RAM Clear ◇

Initializes (resets standard values) data (exposure data, basic data, work area) that is normally backed up.

◇ EAROM Clear ◇

Clears and initializes the EAROM.

【 Default Data 】

- Master cut coefficient 1.0800
- Optical axis feed length 44.00mm
- Cut mask exposure time 1 (OR) 1.0sec
- Cut mask exposure time 2 (PAN) 1.0sec

【 How to Clear the RAM and EAROM 】

1. Turn the power supply OFF. Set **DIP switches 1, 7 and 8** to ON and turn the power supply back ON again.
2. Select **“BK”** with the mode key.
3. Press the START key while pressing the INPUT key to sound the buzzer and display the **“POWER OFF”** message on the display.
4. Turn the power OFF. Set **DIP switches 1, 7 and 8** to OFF.
5. Turn the power supply ON.

Development Temperature Checks and Adjustment

A developing solution temperature of 28 – 31°C is ideal when the “COLD” display on the control panel has gone out.

If the temperature differs, adjust the motor dial located at the right of the processor. When the processor cover is opened after the POWER switch is turned ON, the display “COLD” goes out. To check, turn the POWER switch OFF, wait at least five minutes and then turn the POWER switch back ON again.

Final Assembly and Checks

1. Install the covers.
2. Carry out the various checks.
Carry out a test run in accordance with the instructions laid down in the Instruction Manual.
 - ▶ Carry out a test exposure using the test chart.

● **Input Method**

1. Turn the power supply OFF. Set **DIP switches 1, 7 and 8** to ON and turn the power supply back ON again.
2. **Select "C" with the mode key** to display the optical axis feed length on the display.
3. Using the numerical keypad, key in the desired optical axis feed length.
4. Press the START key while pressing the INPUT key.
5. Turn the power OFF. Set **DIP switches 1, 7 and 8** to OFF and turn the power supply back ON again.

Functions 4 and 5

**Display and Input of the
Cut Mask Exposure Time**

Function 4 (cut mask exposure time 1) for BWL, BW
Function 5 (cut mask exposure time 2) for C, M, Y, Bk

A cut mask marked with registration marks for registering onto a printing press is exposed onto the master. However, the exposure times for ortho film (Silver Master – SLM-R11.F) and panchromatic film (Silver Panplate – SPP-R) vary owing to their differing sensitivities. Input the correct values for the type of film in order to obtain ideal exposure.

● **Input Method for Ortho Film**

1. Turn the power supply OFF. Set **DIP switches 1, 7 and 8** to ON and turn the power supply back ON again.
2. **Select "M" with the mode key** to display the setting.
3. Using the numerical keypad, key in the desired exposure time.
4. Press the START key while pressing the INPUT key.
5. Turn the power OFF. Set **DIP switches 1, 7 and 8** to OFF and turn the power supply back ON again.

● **Input Method for Panchromatic Film**

1. Turn the power supply OFF. Set **DIP switches 1, 7 and 8** to ON and turn the power supply back ON again.
2. **Select "Y" with the mode key** to display the setting.
3. Using the numerical keypad key in the desired exposure time.
4. Press the START key while pressing the INPUT key.
5. Turn the power OFF. Set **DIP switches 1, 7 and 8** to OFF and turn the power supply back ON again.

● Input Method

1. Turn the power supply OFF. Set **DIP switches 1, 7 and 8** to ON and turn the power supply back ON again.
2. Select **"BW"** with the mode key to display the coefficient.
3. Using the numerical keypad, key in the actual master feed length 485mm.
4. Press the START key while pressing the INPUT key to display the new master cut length coefficient.
 - ▶ When keying in the data, select METRIC to input millimeters and INCH to input inches.
5. Turn the power OFF. Set **DIP switches 1, 7 and 8** to OFF and turn the power supply back ON again.

Function 3

Display and Input of the Optical Axis Feed Length


● Checks and Adjustments

The amount that the master is fed to the exposure position after it has been fed is called the "optical axis feed length."

At this time, an ideal state is where the end of the plate is gripped by the feed roller by a few millimeters at the point where the master has travelled past the changeover sheet to the conveyor section. This position is set 28 – 30mm from the end of the plate when a cut mask is exposed.

An insufficient optical axis feed amount leads to defective transport in the conveyor section. An excessive feed amount will result in the master coming away from the feed roller. In either case, adjust as required.

- ▶ Standard feed amount is 44mm. (Setting range is 42 – 46mm.)



5. Verifying and adjusting the optical system

Focus and magnification were thoroughly factory tested, however, if some fault should be found, verify and adjust according to the following.


[Verification and adjustment procedure]

(1) Adjustment for distortion

- Front/back/left/right distortion ⇒ Adjust the original mount in left/right directions or slightly adjust the tilt of the mirror.
- Left/right distortion ⇒ Adjust the original mount vertically.


(2) Adjustment of focus and magnification

- Adjust the entire original mount in left/right directions or adjust the mirror slightly in the left and right directions.
- Adjust the lens magnification scale.



5-1 Adjustment for distortion

[Knowledge of distortion]



In order to copy square and rectangular originals as squares and rectangles, each of the original surface, the lens surface, and exposure surface must be parallel and flat with each other. If the original mount loses its parallelness as shown in the figure above ($B < C$), distortion will occur and a trapezoidal image will be produced where "a" is small and "b" is big.

[Checking for distortion]

Permissible amount of distortion
 Verification at 100% magnification

«Permissible values»

1. $A = B = C = D = 300 \text{ mm} \pm 0.5 \text{ mm}$
2. $E - F = \pm 0.5 \text{ mm}$

1. Insert a suitable chart to measure distortion (square or rectangular).
2. Measure the four sides of the copy. If the difference in measurements between opposite sides is within 0.5 mm then conditions are normal.

■ Adjustment for d'stortion






Image distortion in the front/rear directions (A,B)



When $A > B$

1. Align marks (▲) are placed on the base installation section to mark the original position for reconstruction, however, set the dial gauges respectively on the original mount for quick adjustment.
2. Remove the dome plug and loosen the base securing bolts (cap bolts M8) with the hexagonal spanner (operation side).
3. Move the original mount in direction A.
4. Tighten the cap bolts and verify by making a copy.
5. If outside the permissible values, repeat the above procedure.
 - ▶ When moving the original mount slightly, the job can be done loosening the base securing bolts only on the operation side. When it is necessary to move the original mount longer distances, however, be sure to adjust with the dial gauge set on the back of the operation side as well.



When $A < B$

1. Adjust by moving the original mount at the back of the operation side in direction A, following the procedure for $A > B$ in reverse.






Image distortion in the left/right directions (C, D)



When $C > D$


1. Set the dial gauges on the original mount, both on the operation side and on the back of the operation side.
2. Loosen the open/shut hit bolts (M6).
3. Rotate the open/shut hit bolts to the right in equal amounts. (One revolution equals an alteration of approximately 0.3 mm.)
4. Tighten the lock nuts and verify by making a copy.
5. If outside the permissible values, repeat the above procedure.



When $C < D$

1. Following the adjustment procedure for $C > D$ in reverse, turn the open/shut hit bolts to the left.

5-2 Adjusting focus



[Verifying focus]

1. Set the resolution chart on the original mount and make a copy.

< Resolving power permissible values >


Aperture F22	100%	95%
	8.3 or more	7.1 or more

■ Adjusting the focus

Adjustment by moving the complete original mount in left and right directions

1. Set the lens to 100% with the lens mount handle.
2. Set the dial gauges on the original mount, on both the operation side and the back of the operation side.
3. Loosen the base securing bolts (cap bolts M8) on both the operation side and the back of the operation side.
4. Move the base slightly from the present position in direction A (move in same direction for both the operation side and the back of the operation side).
5. Tighten the base securing bolts and verify by making a copy.
6. If the focus is less clear than it was before, find the true focus by moving the base back towards the original position (direction B).
 - ▶ Adjustment for focus should be done within the permissible distortion values.

5-3 Adjustment of magnification



[Verification of magnification]

1. Place a suitable chart in the original mount to measure the magnification.

< Permissible value > 100% — ± 0.5 mm/300 mm


Adjusting magnification

1. Make a copy and measure the dimensions.

< Finding the magnification >
 Magnification = $\frac{\text{Dimensions of copy image}}{\text{Standard dimensions}} \times 100 (\%)$
 [Ex.] $\frac{297}{300} \times 100 = 99\%$


2. If the result is 99%, as shown in the example, loosen the bracket screws (M4) for the scale.
3. Move the scale bracket in the direction of the arrow so that the cursor line matches 99% on the scale. Secure the bracket.
4. Move the lens mount handle again and set to 100%. Make a copy.
5. If magnification is not within the permissible range, repeat the procedure above.

6. Replacing the mirror



1. Open the front cover.
2. Loosen the screws for the mirror holder and remove the mirror holder.
3. Hold the upper part of the mirror lightly and raise it. Bring it towards you and remove.
4. Set the new mirror correctly.
 - ▶ Be very careful not to scratch or dirty the new mirror during installation.
5. Install the mirror holders.
 - ▶ After replacing the mirror check for distortion, verify focus, and verify magnification.

7. Replacing the copy glass



- The copy surface is secured with suction power and about 2 mm urethane tape is attached on the far side and left side, in two locations against the glass, and is held down with the glass by suction power.
- When changing the glass, be very careful not to let the urethane tape slide or separate. Also, when placing the glass, be absolutely sure not to loosen the glass support (sponge gum).


Removal

1. Open the copy vacuum frame.
2. Open the front cover and cover the mirror.
3. Raise from inside and remove the glass.
 - ▶ Be careful not to scratch the cut mark sheet.

Installation

1. Since installation was made so that there are no spaces between each of the glass holders and the glass, loosen the installation screws (M 4 hexagonal bolts) of the front glass holder.
2. Pushing the far and right sides respectively, install the glass.
3. After confirming that the four pieces of urethane tape have not been damaged, install the front glass holder.
4. Close the vacuum frame and confirm suction and paper passage.

8. Processor and dryer



Scratching of the master in the processor and dryer

Check and adjust according to the following general items.

- | | |
|---|---------------------------------|
| (1) Dirt and foreign substances on the inside of the input guide (emulsion side). | ⇒ Polish clean with a compound. |
| (2) The surfaces of each roller are dirty and they do not rotate smoothly. | ⇒ Rinse with water and clean. |
| (3) The fan in the dryer does not rotate. | ⇒ Check electrical system. |

Wrinkling of the master in the processor and dryer

Check and adjust according to the following general items.

- | | |
|---|-----------------------------|
| (1) The master meanders from faulty setting. | ⇒ Reset the master. |
| (2) Poor cutting of the cutter. | ⇒ Replace the cutter blade. |
| (3) Glue from the tape for securing the master has stuck to parts of the processor and conveying section (rollers, etc.) causing the master to meander. | ⇒ Clean. |
| (4) Foreign matter and have stuck to the processor input guide. | ⇒ Adjust and clean. |

-
- (5) The wringer roller finger line and the roller line in the developer and fixer tanks are not matched left and right. ⇒ Adjust.
 - (6) Each finger exhibits unevenness or foreign matter has stuck there. ⇒ Adjust and clean.
 - (7) The dryer temperature setting is too high. ⇒ Lower the temperature by slightly turning the adjustor on the thermostat to the left.
- ☆ When scratches or wrinkles appear on the master, find the part in the process where it occurred before fixing.

Electrical System

Contents

1. Outline	1
1-1 Introduction	1
1-2 System outline	1
1-3 Operation flowchart (BWL)	2
1-4 Operation flowchart (BW, C, M, Y, and BK)	3
2. Problems and Diagnosis	4
2-1 Special warnings	4
2-2 Checking the power supply	4
2-3 Function of each fuse	4
2-4 When each fuse blows	6
3. Power Supply Voltage Check	7
3-1 Verifying the power supply voltage at the place of installation	7
3-2 Verifying the AC 100V power supply on the second side	7
3-3 Verifying power supply voltage on the board	8
3-4 Verification of the regulator power supply voltage	9
3-5 Verification of DC power supply voltage for relay	10
4. Troubleshooting	11
4-1 The CPU does not operate.	11
4-2 DC 24 does not output.	12
4-3 Reflection light source does not illuminate.	13
4-4 Transmission light source (optional) does not illuminate.	14
4-5 MC 1 does not work.	16
4-6 Dryer heater does not operate.	17
4-7 Dehumidifier does not operate.	19
4-8 Vacuum pump does not operate.	20
4-9 Door switch does not operate.	21
4-10 Developer heater does not operate.	22
4-11 The processor motor does not operate.	23
4-12 Dryer fan does not operate.	24
4-13 Flash light source does not illuminate.	25
4-14 Cut mark lamp does not illuminate.	26
4-15 Shutter does not open.	27
4-16 Master does not feed (feed motor does not rotate forward).	28
4-17 Master does not transfer (feed motor does not reverse).	29
4-18 Master does not convey (conveying motor does not operate).	30
4-19 Cutter does not advance.	31
4-20 Cutter does not retreat.	32
4-21 Solenoid valve air blow does not work.	33
4-22 Master feed clutch does not work.	34
4-23 Contact screen frame does not move up and down.	35


5. Verification section (maintenance mode)	36
5-1 LEDs for CPU board signal verification	36
5-2 CPU board LED chart	36
5-3 Maintenance mode	38
5-4 DIP switch settings	42
6. CPU Board and panel board	43
6-1 CPU board trouble	43
6-2 Symptoms when CPU behaves abnormally	43
6-3 CPU board troubleshooting	44
6-4 Re-verification before changing CPU board	45
6-5 Symptoms when panel board behaves abnormally	46
6-6 Countermeasures	46
6-7 Erroneous operation caused by noise	46
6-9 Caution to be taken when changing the CPU board	47
6-8 Other faulty operation	47
6-10 ROM and CPU replacement	48

1. Outline

1-1 Introduction


This service manual was written to cover repairs up to print board replacement.

1-2 System outline




This unit uses an 8085 series microprocessor in the control section and all signals from each sensor switch are sent to the control section as input signals. Output signals from the control section operate the relays which operate each electrical device.


The process occurs in the following order:



1-3 Operation flow chart (BWL)



1-4 Operation flowchart (BW, C, M, Y, and BK)



2. Problems and Diagnosis

2-1 Special warnings

1. The terminals inside the electric supply unit with the following numbers are still alive even when the power switch is turned OFF. Observe caution. VL-WL, VL1-WL1, VL3-WL3, UL4-XL1, and UL1-XL1
2. When changing any of the electrical parts, be sure to **turn the switch OFF in the electrical supply box from which power is supplied to this unit via the power cord**. Or, detach the power supply cable.
3. Be sure to cut the power before doing any repairs on the revolving parts, the cutter, and the chain mechanism.

2-2 Checking the power supply

The power supply relates to all troubles. Therefore, be sure to check the power supply first before engaging in further troubleshooting.

1. Check the suitability of the **voltage discriminating tap** of the power supply transformer.
2. **Check that the input power supply voltage** to the input cord is normal.
3. **Check for blown fuses in the electric supply box**. Refer to 2-4. If a fuse is found to be blown, replace with a fuse of the correct standard. If the fuse blows again at this time, replace after finding the cause.


[Caution] *When checking the electric supply unit, proceed only after turning the original power source OFF, in order to prevent electric shock.*

4. If the AC power supply is okay, next check the DC power supply. Refer to 3-4 and 3-5 for checking the DC power supply.

2-3 Function of each fuse

The electric supply unit is found below the master loading section and is made up of various electrical parts. Turn the power switch and the original power source OFF before changing fuses or checking the circuit. Use fuses of same rated capacity and type. Do not install anything which differs. (Use of anything different will cause damage to the unit.)

This machine uses fast blow type fuses.



- 1 Reflection light source fuse (F1)
A 20A glass fuse protects the reflection light source circuit.
- 2 Transmission light source fuse (F6)
A 20A glass fuse protects the permeable source circuit.
- 3 Dryer heater source fuse (F2)
A 3A glass fuse protects the dryer heater circuit.
- 4 Transformer fuses for high power circuit (F3, F4)
10A glass fuses protect the transformer for the high power circuit.
- 5 Dehumidifier source fuse (F5)
A 5A glass fuse protects the dehumidifier circuit.
- 6 Vacuum pump fuse (F7)
A 2A glass fuse protects the vacuum pump circuit.
- 7 Fuses for low power circuit (F8, F9, F10, F14)
One 2A and three 1A glass fuses protect the low power circuit.
8. Developer heater fuse (F11)
A 5A glass fuse protects the heater circuit inside the developer tank.
- 9 Processor motor fuse (F12)
A 1A glass fuse protects the processor drive motor circuit.
- 10 Dryer fan fuse (F13)
A 3A glass fuse protects the dryer fan circuit.

**2-4 When each filter
blows**

- | | |
|-----------------------|---|
| 1. When F1 blows | The reflection light source does not illuminate. |
| 2. When F2, TF1 blow | The dryer heater does not operate. |
| 3. When F3, F4 blow | All operations stop or no operations start. |
| 4. When F5, TF2 blow | The dehumidifier does not operate. |
| 5. When F6 blows | The transmission light source (optional) does not operate. |
| 6. When F7 blows | The vacuum pump does not operate. |
| 7. When F8, F9 blow | Devices other than the developer heater, processor motor, and the dryer fan do not operate. |
| 8. When F10, F14 blow | Devices other than the cutter motor, dehumidifier, developer heater, processor motor, and the dryer fan do not operate. |
| 9. When F11 blows | The developer heater does not operate. |
| 10. When F12 blows | The processor heater does not operate. |
| 11. When F13 blows | The dryer fan does not operate. |


3. Power Supply Voltage Check

3-1 Verifying the power supply voltage at the place of installation

The voltage should read $\pm 10\%$ of the basic voltage when measured with terminals [VL] and [WL] inside the electric supply unit (even when under full load).

The same applies for [VL1], [WL1] and [VA], [WA].


$\pm 10\%$ of basic voltage



3-2 Verifying the AC 100V power supply on the second side


The voltage should read **AC 100 V** $\pm 10\%$ of the basic voltage when measured with terminals [UL1] and [XL1] inside the electric supply unit (even when under full load).

ac 100V $\pm 10\%$





3-3 Verifying power supply voltage on the board

Measure in the check locations given below on the board.



[Caution] Use a digital type tester as your measuring device.
 When using an analog type tester, use one which gives an instantaneous response.


3-4 Verification of the regulator power supply voltage



DC 5V : For CPU


DC 12 V : For optical integrator

3-5 Verification of DC power supply voltage for relay



AC 18 V is supplied to the relay board from TR 2 to CN82 [3] [8] - [6] [9] .

On the relay board, AC 18 V is rectified to DC 24 V and goes from CN82 [1] [P24] - [2] [E24] to terminals [TM41 - 43] [P24] - [TM44 - 46] [E24] , and is supplied to each fixture and board, etc.




4. Troubleshooting

4-1 The CPU does not operate.

Verification fuses
F8, 9, 10, 14


DC 5V and DC 24V are necessary for the CPU.



【 Caution 】 For CPU board trouble, be sure to check the output voltage at the power supply unit output terminals on the CPU board.

4-2 DC 24 does not output.


Verification fuses
F9, 10, 14



4-3 Reflection light source does not illuminate.

Verification fuse


F1




4-4 Transmissior light source (optional) does not illuminate.


Verification fuse

F6





4-5 MC 1 does not work.





[Note] Faulty contact may be considered.

If there is no continuity between MC1 [A1] [10] and [A2] [X1], change MC1. If there is continuity, contact is faulty. If contact is faulty, change contact or change MC1.

4-6 Dryer heater does not operate.

Verification fuse **F2**






【 Note 】 Check for faulty contact between MC3 【 2 】 【 V2 】 and 【 4 】 【 V3 】 . If there is faulty contact, change contact or replace MC3.

4-7 Dehumidifier does not operate.

Verification fuse


F5



4-8 Vacuum pump does not operate.

Verification fuse


F7



4-9 Door switch does not operate.

Verification fuse


F14



4-10 Developer heater does not operate.

Verification fuse

F11




[Note] The developer heater is deliberately turned [OFF] when the main light source is on because of the limit on electrical capacity.

4-11 The processor motor does not operate.


Verification fuse

F12



4-12 Dryer fan does not operate.


Verification fuse
F13




4-13 Flash light source does not illuminate.

Verification fuses

F8, 9




4-14 Cut mark lamp does not illuminate.



4-15 Shutter does not open.


Verification fuses
F8, 9



[Note] Check beforehand whether or not there is a machine related problem. In particular, the shutter may not open if the lens cap is on.


4-16 Master does not feed (feed motor does not rotate forward).

Verification fuses
F8, 9




4-17 Master does not transfer (feed motor does not reverse).

Verification fuses
F8, 9




4-18 Master does not convey (conveying motor does not operate).

Verification fuses
F8, 9



4-19 Cutter does not advance.


Verification fuses
F8, 9



[Note] Turning the power [ON] when the cutter has not triggered the limit switch (when in the central position), automatically returns it to the starting point. Be very careful when this happens.


4-20 Cutter does not retreat.

Verification fuses
F8, 9



4-21 Solenoid valve air
blow does not
work.

Verification fuses
F8, 9




[Note] Check that the vacuum pump is working.

4-22 Master feed' clutch
does not work.


Verification fuses

F9, 14



4-23 Contact screen frame does not move up and down.

Verification fuses
F9, 14




[Note] A faulty copy frame can also be considered. Check with the copy frame open.

5. Verification section (maintenance mode)

5-1 LEDs for CPU board signal verification

These LEDs allow status verification of the input/output signals to and from the board.

CPU board Parts installation side



5-2 CPU board LED chart

● LEDs for input verification

LED No.	Name	Times illuminated	PPI2 input
1	CPU	Illuminates when CPU leads.	
2	Light integrator	Flashes during pulse input.	PA 0
3	Photo interruptor	Flashes when the notch part of the sensor code board comes to the interruptor position (pulse IN).	PA 1
4	Developer heater	Illuminates when the developer tank heater is operating.	PA 2
5	Cutter starting point	Cutter block is not in the starting position. Illuminates when the starting point switch (LS2) is OFF.	PA 3

6	Cutter reversal position	Cutter block is not in the starting position. Illuminates when the starting point switch (LS3) is OFF.	PA 4
7	Door switch	Illuminates when operation panel is completely closed (LS1 is ON).	PA 5
8	Master out sensor	Illuminates when master discharges and master output switch (LS4) is ON.	PA 6
9	Contact screen sensor	Illuminates when contact screen is set (LS5 is ON).	PA 7
10~15	Not in use		
16	Master end sensor	Illuminates when master is not at the conveying input guide (not at sensor SE1).	PB 4
17	Master seam sensor	Illuminates when master senses the seam (not at sensor SE2).	PB 5
18	Master convey timing sensor	Illuminates when master is not at the conveying guide (not at sensor SE3).	PB 5
19	Not in use		

● LEDs for output verification

LED No.	Name	Times illuminated	PPI2 input
20~28	Not in use		
29	Light source	Illuminates when reflected/permeable (optional) light source illuminates.	PB 1
30	Dryer heater	Illuminates when the dryer heater operates.	PB 2
31	Clutch	Illuminates when the master feed clutch operates.	PB 3
32	Feed motor forward rotation	Illuminates when the master feed motor feeds the master.	PB 4
33	Feed motor reverse rotation	Illuminates when the master feed motor conveys the master to the developing section.	PB 5
34	Transfer motor	Illuminates when the conveying motor rotates.	PB 6

35	Shutter	Illuminates when the shutter is open.	PB 7
36	Vacuum pump	Illuminates when vacuum is operating.	PC 0
37	Cut mark lamp	Illuminates when lamp for cut mark copy illuminates.	PC 1
38	Contact screen	Illuminates when the solenoid (SOL2) for moving the vacuum sheet installation frame up and down is ON.	PC 2
39	Cutter	Illuminates when the cutter is operating.	PC 3
40	Flash lamp	Illuminates when the flash lamp is illuminated.	PC 4
41	Air blower	Illuminates when solenoids (SOL4, 5) for the air blower operate.	PC 5

5-3 Maintenance mode

- Function** 【 Function 1 】 Manual operation (manual check)
MANUAL MODE
- 【 Function 2 】 Master cut coefficient display and coefficient generation
through input of actual measurements
MASTER CUT DATA
- 【 Function 3 】 Display and input of optical axis feed length
AXIS FEED DATA
- 【 Function 4 】 Display and input of cut mark exposure time 1 (for
BWL, BW)
CUT MARK 1 (OR) TIME
- 【 Function 5 】 Display and input of cut mark exposure time 2 (for C,
M, Y, BK)
CUT MARK 2 (PAN) TIME
- 【 Function 6 】 RAM clear/EAROM clear (initial value reset)
RAM CLEAR

Operation 1 Turn power supply [ON] after putting DIP switch 8 to [ON], in order to enter the maintenance mode.

【 Note 】 When inputting (writing) numerical values with functions 2 to 5, switch both DIP 1 and 7 to [ON], in addition to DIP 8. (EPROM input)

Operation 2 Select function with the mode key. BWL – BK of the normal mode correspond to functions 1 to 6.

	Function 1	Function 2	Function 3	Function 4	Function 5	Function 6
Mode display cursor	— BWL	BW	C	M	Y	BK

Operation 3 **【 Function 1 】** Press corresponding key.

【 Function 2 – 5 】 Input → Press START key while holding down the INPUT key.

【 Function 6 】 Press START key while holding down the INPUT key.

【 Function 1 】 Manual operation

Select “BWL” with mode key.

Allocation of each key

Key- 1: Cutter

2: Dryer heater

3: Clutch

4: Feed motor (FORWARD)

5: Feed motor (REVERSE)

6: Transfer motor

7: Shutter

8: Vacuum pump (suction only)

9: Cut mark lamp

0: C. S. solenoid

∴: Solenoid valve

C: Flash lamp

FOCUS: Main lamp (Reflected/permeable)

- 【 Note 】**
1. [ON] only while key is pressed down.
 2. Two or more operations cannot be done at the same time.
 3. Do not keep the dryer heater and main lamp [ON] for long periods.

【 Function 2 】 Master cut coefficient display and coefficient generation through input of actual measurements

Select "BW" with mode key.

1. The master cut coefficient is displayed when entering this mode.
2. Input the actual measurements and generate the master cut coefficient.
 - ① Enter, subtracting 30 mm from the actual master length which was sent. Accuracy improves by setting FEED at 480 mm.
 - ② Input by pressing the START key while holding down the INPUT key.

【 Function 3 】 Display and input of the optical axis feed length

Select "C" with the mode key.

1. The optical axis feed length is displayed when entering this mode.
2. Enter the optical axis feed length. The standard is 44 mm. (42 mm – 46 mm)
3. Input by pressing the START key while holding down the INPUT key.

【 Note 】 The master cut coefficient is not multiplied by this value.

【 Function 4 】 Display and input of the cut mark exposure time 1 (for BWL, BW)

Select "M" with the mode key.

1. The cut mark exposure time 1 (for BWL, BW) is displayed when entering this mode.
2. Enter the exposure time.
3. Input by pressing the START key while holding down the INPUT key.

【 Function 5 】 Display and input of the cut mark exposure time 2 (for C,M, Y, BK)

Select "Y" with the mode key.

1. The cut mark exposure time 2 (for C,M, Y, BK) is displayed when entering this mode.
 2. Enter the exposure time.
 3. Input by pressing the START key while holding down the INPUT key.
-

[Function 6] RAM clear/EAROM clear (initial value reset)

Select "BK" with the mode key.

1. When the START key is pressed while holding down the INPUT key after entering this mode, RAM and EAROM are cleared simultaneously (initial value reset).
2. The buzzer sounds and the POWER OFF message is displayed.
3. Turn power OFF.

RAM clear

Initializes exposure data, basic data, and work area, etc, and regular data which has been backed up (resets to default values).

Initialize data (reset values)

	BWL	BW	C	M	Y	BK
BMIN	—	0.6	0.6	0.5	0.4	0.6
BMAX	—	1.5	1.5	1.6	1.5	1.5
Tm (sec)	—	40.0	50.0	50.0	50.0	20.0
Tf (sec)	—	20.0	20.0	20.0	20.0	15.0
TI (sec)	15.0	15.0	15.0	15.0	15.0	15.0
TADJ	1.00	1.00	1.00	1.00	1.00	1.00
DMIN	—	0.06	0.06	0.06	0.06	0.06
DMAX	—	1.70	1.70	1.70	1.70	1.70
FEED	480mm					
m%	100%					
COUNT	0					

EAROM clear

- ① If DIP switches 1 and 7 are both [ON] (writing possible), clear the contents of EAROM and initialize (reset to default values).

Initialize data

Master cut coefficient : 1.0800
Optical axis feed length : 44.00 mm
Cut mark exposure time 1 (OR) : 1.0 sec
Cut mark exposure time 2 (PAN) : 1.0 sec

② If DIP switches 1 and 7 are both OFF (writing impossible), EAROM will not initialize. However, the work area will be initialized and data is reset by reading the set values anew from EAROM.

Data backup check

Data may be damaged through expiration of the internal battery-operated backup function when the machine is not used for long periods. If this should happen, the machine will automatically judge this when power is turned on. After clearing RAM the machine will display DATA ERROR and POWER [OFF] messages while intermittently sounding a buzzer. The operator should turn [OFF] the power after pressing the reset key and canceling the error. To make copies, any necessary data should be reset over the standard data which was set when RAM was cleared. If error warnings appear every time the power is turned on, the problem may have its origin in the hardware.

5-4 DIP switch settings

	ON	OFF	Comments
1	EAROM input	Normal	Hard protect
2	Inch designation	Millimeter designation	Feed units
3	50 Hz	60 Hz	Jam time
4	Stationary clock	Light integrator	Main exposure time control
5	Air blow 10 seconds	Air blow 5 seconds	For cooling
6	Not in use.	Normal	
7	EAROM input	Normal	Soft protect
8	Maintenance mode	Normal	For servicemen

[Note] Be sure to turn power [OFF] before setting DIP switches.

6. CPU Board and panel board


6-1 CPU board trouble

1. A microcomputer is included in the main unit. When trouble occurs, the origin should be seen as being in either the control circuit or the microcomputer, resulting from over voltage.
2. The microcomputer runs according to the program. Signals from the master sensors and micro-switches can be confirmed with the input/output verification LEDs (red), and verification should be made that these are running normally. Refer to 5-2.
3. After verification, press the panel keys and confirm that the entries appear on the display. If input is completely impossible, it will be necessary to replace the CPU board and panel board.
Confirm also the power supply voltage of the CPU (5 V, 24 V).
Refer to 3-3.

6-2 Symptoms when CPU behaves abnormally

1. Screen displays meaningless characters when the power is turned [ON] .
2. Nothing is displayed.
3. Junk characters are occasionally displayed.
4. The display is normal, but it does not receive entered characters (key input impossible).
5. Basic data cannot be input.
6. When recalled, the contents of the data change.
7. Light source, cutter motor, heater, and other devices operate irregularly.
8. Mode selection cannot be made.


6-3 CPU board troubleshooting



6-4 Re-verification before changing CPU board


Changing the CPU is the ideal, however, the ICs listed below which use the sockets should be checked first as bad socket and connector contact could be the cause of failure. Test and make repairs according to the procedure below.

[Note] Do not proceed until at least three minutes after the power has been cut.



(1) Slightly lift out the 8085 CPU ①, ROM ②, RAM ③, and EAROM ④ with a screwdriver or special tool, as shown below.

(2) Re-insert.



-
- (3) Remove connectors 1 CN1 and 2 CN100. Re-install.
 - (4) Do the same for the other connectors.
 - (5) Turn [ON] the power and check for normal operation. If operation is still not normal there is a fault in the CPU. Change the board. Refer to 6-9.

6-5 Symptoms when panel board behaves abnormally

- (1) Display has completely vanished or is black.
- (2) Only one character is not displayed while the others are.
- (3) Broken characters are displayed. Unit operates normally.

6-6 Countermeasures

- (1) Check the flat cable connectors CN1 and CN100 to which the panel board and CPU board are connected.
- (2) Replace parts or change panel board.
- (3) CPU trouble is suspect with the following symptoms.
 - Nothing is displayed
 - Display changes irregularly
 - Junk characters other than numbers and letters are displayed.

6-7 Erroneous operation caused by noise

- (1) Results of calculation differ despite use of same data.
- (2) Light source instantaneously goes out after illuminating. Or, result of calculation becomes "0".
- (3) Light source cuts during exposure.
- (4) Numerical values change during exposure.
- (5) Exposure calculation speed changes.
- (6) Irregular and faulty operation of dryer fan and heater.
- (7) Others.

◆ Noise countermeasures ◆

- Ground machine separate to other devices.
- If unit appears to be influenced by other machines, do something about or take away the cause of noise.
- Check whether or not leaking in the terminal part of the camera light source (especially zeno super) is being recognized.

6-8 Other faulty operation


- (1) After machine installation is completed, turn the processor heater and reflection light source [ON]. Check for faulty CPU operation.
- (2) If the above conditions appear when the AC 100 V 2nd power supply is 87 V or less, the capacity of the main power supply is insufficient. Have an electrician make the necessary alterations in the main power supply.
 - When the power line itself is too narrow ... AWG 14 power line is necessary for this machine.
 - The electric supply unit, before connecting to the machine, had exceeded the capacity limit.

6-9 Caution to be taken when changing the CPU board

- (1) Set the DIP switches on the replacement board to the same settings as the DIP switches on the original board.
- (2) Replacing the memory data
Exchange the EPROM chip on the new board with the EPROM chip on the old board. The data is stored on the EPROM chip from the old board. After exchanging, recall the data and check that there are no errors.

◆ Changing EAROM chip ◆

- Ⓐ Cut the main power supply and wait for three minutes.
- Ⓑ Remove the EAROM chip with a screwdriver or special tool, as shown in Fig. 2.
 - 【 Note 】 Raise each side little by little when using a screwdriver.
- Ⓒ Following “Ⓑ”, above, also remove and replace the ROM chip of the new board.
- Ⓓ Turn DIP switch 8 [ON], DIP switches 1 and 7 [OFF], and clear RAM.
- Ⓔ Install the ROM chip removed from the new board onto the old board and return to the factory.
 - 【 Note 】 Do not touch or allow any bodily contact with the legs of the IC. Place on an electro-conductive mat when not in use.




(3) Input the data by hand if errors were found in the data when checking after the replacement, or if data is faulty. Refer to 5-3 and 5-4.

If the old data is written down, the operation above is not necessary. Re-input the data directly into the panel.

6-10 ROM and CPU replacement




- (1) Follow the procedure in 6-9 item 2.
- (2) Return old parts to the factory.



1. Unless otherwise specified, be sure to use AWG20 for the electrical wires. 相違なき電線は、AWG20を使用すること。
2. For the ground wires, use a toothed washer and be sure to ground securely. 接地線は、歯付きワッシャーを使用し、確実に接地すること。
3. Be sure to attach a GROUND plate. 必ず接地板を貼ること。
4. Cover legs of Z-top and noise-killer with insulating tubing. Zトップの足とノイズキラーの足は、必ず絶縁管で被ること。





NO.	TITLE	DWG No.
1	WIRING SYSTEM DIA.	HCS32257
2	DISTRIBUTING BOARD 1 CONNECTION DIA.	HCM31226
3	DISTRIBUTING BOARD 2 CONNECTION DIA.	HCM41227
4	DEFIMIDFIRE CONNECTION DIA.	HCS51599
5	TRANS. LIGHT CONNECTION DIA. (OPTION)	

1HW-112



—|—|— : #CR-1 或 #CRU-112


—|—|— : #IS1585



1. Unless otherwise specified, be sure to use AWG20 for the electrical wires.
稀な台の電線は AWG20 を使用する。
2. For the ground wires, use a foiled washer and be sure to ground securely.
T-2 9-3TL の電線は、箔付ワッシャーを用いて確実に接地すること。
3. Be sure to attach a GROUND plate.
T-2 9-3TL の基板に必ず接地板を貼ること。
4. Cover legs of Z-lap with insulating tubing.
Zラップの足には、絶縁チューブをかぶせること。

DISTRIBUTING BOARD 1
CONNECTION DIA.

HCM31226



2	4	6	8	10	12	14	16	18	20	22	24	26	28	30	32	34
V _{DD}	PC1	PC3	PC5	PC7	PC9	PC11	PC13	PC15	PC17	PC19	PC21	PC23	PC25	PC27	GND	GND
1	3	5	7	9	11	13	15	17	19	21	23	25	27	29	31	33
V _{DD}	PC0	PC2	PC4	PC6	PC8	PC10	PC12	PC14	PC16	PC18	PC20	PC22	PC24	PC26	TM	GND










PHOTO SENSOR SE1, SE2, SE3 J1 J2 J3
 LIGHT METER (PHOTO DIODE) PANEL PCB CN100 PHOTO INTERRUPTER SE4 J4
 REGULATOR RE1 #EYG300/01-UTLC
 LIGHT METER PCB HCB44131
 SENSOR PCB HCB44128
 CPU PCB CPU基板 HCB34119
 NOISE FILTER NF3 #ZGB2201-01U
 DISTRIBUTING BOARD 1 TERMINAL (TM42~TM53)

0.3mm²-2C (SHIELD WIRE)
 FLAT CABLE 34C
 AWG20
 AWG18
 AWG22
 *ENB-201D-14A
 J18
 J19
 J20
 J21
 J22
 J23
 J24
 J25
 J26
 J27
 J28
 J29
 J30
 J31
 J32
 J33
 J34


1. Unless otherwise specified, be sure to use AWG22 for the electrical wires.
指定なき電線は、AWG22を使用すること。
2. For the ground wires, use a toothed washer and be sure to ground securely.
アースは歯付ワッシャーを用いて、確実にアースすること。
3. Cover legs of Z-lap with insulating tubing.
Zラップの足には、チューブをかぶせること。



SENSOR BOARD
ARRANGEMENT DIA.
HCS42251

No.	品名	型番 (メーカー)	個数
1	3端子レギュレ-9	MC7812CT (モロ-ラ)	1
2	トリマ- サ-ネット	67W R1KΩ (ベ-ツマ-)	3
3	抵抗	390Ω 1/2W	3
4	抵抗	1.2KΩ 1W	3
5	LEDランプ	TLR102A (東芝)	3
6	EIシリ-ズ コネ-9	171825-4 4P (AMP)	3
7	EIシリ-ズ コネ-9	171825-6 6P (AMP)	1
8	ワ-ワ-4-7-ツシ	TB-300 (名取)	2
9	ワ-ワ-4-7-ツシ	TA-310 (名取)	2
10	センサ基板	HCB44128	1
11	OA7ロ-ツ7ソ-バ-シ-ル	HCC51336	(1)

	OA7ロ-ツ7ソ-バ-シ-ル	DATE	APPROVED
0	E E 0 4 3 3		







② トリマ- 実装方法



実装後、右 (CW)へ 18回以上回して、感度を最大にしておく。

SENSOR PCB
ARRANGEMENT P1A.


HC R42673




- ※ 1. ①はコネクターの線番です。
- 2. AC100Vラインは、単体間隔 2mm以上厳守。 AC100VラインとDC24Vラインの間隔は 2mm以上とする。
- 3. DC24Vラインの単体間隔は 1.2mm以上とする。
- 4. U1, X1, P24, E24は分岐回路で、コネクターの入りラインは、太くして下さい。



→ #CRU112 RY2~RY4 → MYZ AC100V
 → #151585 RY1, R5~R15 → MYZ DC24V




- ※ 1. ◎ はコネクターよりの線番です。
- 2. AC100Vラインは、単体間隔 2mm以上厳守。 AC100VラインとDC24Vラインの間隔は 2mm以上厳守。
- 3. DC24Vラインの単体間隔は 1.2mm以上厳守。
- 4. U1, X1, P24, E24 は分岐回路で、コネクターよりの入力ラインは、太くして下さい。



1	CN82	4	CN83	4	CN84	4	CN85	4	CN86	4
10	P24	10	U1	12	Z1	22	Z1	22	11	U1
19	E24	19	5	3	27	23	27	23	18	14
9	8	9	XL4	U5	17	24	17	24	15	X1


→ #CRU12 RY2~RY4 → MYZ AC100V
 → #1S1585 RY1,R5~R15 → MYZ DC24V



No	品名	規格	メーカー	数量
	1/L-基板	HCB34/40-01		1
RY15~RY15	1/L-	MYZ DC24V	直石	12
RY7~RY4	1/L-	MYZ AC100V	直石	3
RY1~RY15	1/L-177-1	PT08-02	直石	15
RY7~RY15	1/L-止×金具	PTC-P	直石	15
RF1	整流スプツ	S4VB10	新電元	1
RF2	整流スプツ	S2VB40	新電元	1
C	电解コンデンサ	470μF 35V	松下	1
① ~ ③	スプツキタ	CRU112	ト-7	3
④ ~ ⑥	ダイヤード	1S1585	東芝	12
CN80~CN81	EIコネクタ	1-171825-Q	AMP	2
CN82~CN86	コネクタ	350431-1.6P	AMP	5
⑬	7-97477-2	TB-300	ト-7	4
⑭	7-97477-1	TA-305	ト-7	4
⑮	0A7077No.2	EE0444~		1

OA BLOCK No.	SEAL
	EE0444
o	EE0444-01
	EE0444-02
	EE0444-03
	EE0444-04

RELAY BOARD
ARRANGEMENT DIA
HCR42709




~~DELETE~~

~~DELETE~~

No	品名	規格	メーカー	数量
	リリ基板	HCB34140-01		1
RY1	リリ	MYZ DC24V	直石	12
RY2	リリ	MYZ AC100V	直石	3
RY15	リリ	PY08-02	直石	15
RY1	リリ	PYC-P	直石	15
RF1	新電元	S4VB10	新電元	1
RF2	新電元	SZVB40	新電元	1
C	松下	470F 35V	松下	1
①	ト-7	CRU112	ト-7	3
④	東芝	1.51585	東芝	12
CN80~CN81	AMP	1-171825-0P	AMP	2
CN82~CN86	AMP	350431-1 6P	AMP	5
⑬	ト-7	TB-300	ト-7	4
⑭	ト-7	TA-305	ト-7	4
⑯	ト-7	EE0444~		1

OA BLOCK No. SEAL
EE0444
EE0444-01
EE0444-02
EE0444-03
EE0444-04

RELAY BOARD
ARRANGEMENT DIA
HCR42709




LIGHT METER CIRCUIT

積算光量計回路図

HCS42256

0A7	ロツクツンバ-	DATE	APPROVED
0	EE0434		


No	品名	型番 (メーカー)	個数
1	OP. AMP	MC14574 (ヒロハラ)	1
2	C ² MOS	TC4066BP (東芝)	1
3	C ² MOS	TC4538BP (東芝)	1
4	フォトカプラ	PC827 (シャ-プ)	1
5	トランジスタ	2SC2320 (三菱)	1
6	ダイオード	1S1588 (東芝)	1
7	ウェットタイオード	RD5.6EB (NEC)	2
8	抵抗	1.2K 1/4W	1
9	抵抗	2 K 1/4W	1
10	抵抗	3.6K 1/4W	1
11	抵抗	10 K 1/4W	1
12	抵抗	12 K 1/4W	2
13	抵抗	680K 1/4W	1
14	抵抗	1 K 1/2W	1
15	抵抗	2.2K 1W	1
16	トリマ抵抗	67W R 500Ω (ベツマン)	1
17	スチロコンデンサ	51PF CQ08S-2B-51R00-J02	1
18	SHA コンデンサ	33μF/25V	1
19	電解コンデンサ	10μF/35V	1
20	セラミックコンデンサ	0.1μF/50V	1
21	セラミックコンデンサ	0.01μF/50V	2
22	EIシリコンコンデンサ	171825-2 2P (AMP)	1
23	EIシリコンコンデンサ	171825-3 3P (AMP)	2
24	ワンタッチブリッジ	TB-300 (名取)	2
25	ワンタッチカラー	TA-310 (名取)	2
26	光量計基板	HCB44131	1
27	OA7ロツクツンバ-シル	HCC51337	(1)



⑬ トリマ調整方法

反射光源点灯時に、テストポイント〔TP〕のパルス周期を、
100 msec に調整する。



チップ端子取付方法 (GND, TP)



DA BLOCK SEAL	REVISION	DATE	APRV
EE0431		28.3.81	H. MATSUMURA
-01			
-02			
-03			
-04			

No	名称	規格	メーカー
①	トランジスタ	M54876P	三菱
②	TTL IC	SN74LS08	
③	LSI PPI	P8255	
④	TTL IC	SN74LS32	
⑤	TTL IC	SN74LS138	
⑥	TTL IC	SN74LS74	
⑦	LSI ROM	P27256 32K	
⑧	TTL IC	SN74LS14	
⑨	IC CMOS	TC4009BP	東芝
⑩	LSI RAM	HM6264LP-15	日立
⑪	RESET IC	PST519A	三菱
⑫	TTL IC	SN74LS373	
⑬	LSI EPROM	X2210	TI社
⑭	LSI CPU	P8085A	
⑮	TTL IC	SN74LS245	
⑯	74171	PC827	三菱
⑰	74171	HC-10491LSZMHZ	日本電産
⑱	74171	25A999	三菱
⑳	74171	25C2320	
㉑	74171	M54519P	
㉒	74171	PKB24SPC-3601	村田
㉓	抵抗	560Ω 1/4W	
㉔	抵抗	510Ω 1/4W	
㉕	抵抗	10KΩ 1/4W	
㉖	抵抗	15KΩ 1/4W	
㉗	抵抗	330Ω 1/4W	
㉘	抵抗	1KΩ 1/4W	
㉙	抵抗	510Ω 2W	
㉚	抵抗	2.2KΩ 1W	
㉛	抵抗	22KΩ 1/4W	
㉜	抵抗	TLR102A	東芝
㉝	抵抗	TLR109A	東芝
㉞	抵抗	0.01μF 50V	
㉟	抵抗	33μF 25V	
㊱	抵抗	FZ0H474Z	日本ケミコン
㊲	抵抗	10PF 50V	NEC
㊳	抵抗	4.7KΩ 1/8W	
㊴	抵抗	22KΩ 1/8W	
㊵	抵抗	10KΩ 1/8W	
㊶	抵抗	330Ω 1/8W	
㊷	抵抗	A6D-8103	日立
㊸	抵抗	MFC-34RPM	本邦
㊹	抵抗	35042B-1 ZP	AMP
㊺	抵抗	MFC-10RPM	本邦
㊻	抵抗	MFC-20RPM	本邦
㊼	抵抗	J71825-3 3P	AMP
㊽	抵抗	FP-213A	村田
㊾	抵抗	FP-213A	村田
㊿	抵抗	FP-213A	村田
14	抵抗	100μF 16V	
15	抵抗	0.5-028-360T	YIL
16	抵抗	0.5-040-360T	YIL
17	抵抗	0.5-018-360T	YIL
18	抵抗	YIL	YIL
19	抵抗	YIL	YIL
20	抵抗	HCB34119	

CPU BOARD
ARRANGEMENT DIA
HCR32671



SILVER MASTER CP-TONE 310

Service Manual

No.4106A 8809 Printed in Japan